



Minute™ Plasma Membrane/Protein Isolation and Cell Fractionation Kit

Catalog number: SM-005

Description

Free of detergents and EDTA, the Minute™ kit is a next-generation solution for native plasma membrane (PM) isolation and cell fractionation. It offers exceptional convenience and consistency by eliminating the variability often seen with traditional methods such as homogenization, density gradient centrifugation, and two-phase partitioning.

How it works: Cells/tissues are first sensitized by buffer A before passing through the proprietary filter in a zigzag manner when high-speed centrifugal force is applied, resulting in a cell lysate containing ruptured cell membranes and intact nuclei. As a result, the nuclear contaminations are virtually eliminated. PM is further separated from the cell lysate (a mixture of crude membranes, intact nuclei, cytosol proteins and organelles) by subsequent differential and density centrifugation with a regular tabletop microcentrifuge. 5 distinct cell fractions (total membrane, PM, cytosol, nucleus and organelles) can be obtained at the completion of the protocol. The procedure can be completed in less than 45 minutes.

Applications

The kit is designed to rapidly isolate native membrane proteins from cultured cells or tissues for applications such as SDS-PAGE, immunoblottings, ELISA, IP, membrane protein structure analysis, 2-D gels, enzyme activity assays and other applications. This kit provides the most rapid method currently available for preparation of native membrane proteins.

Kit components (50 preps):

1. 25 ml buffer A
2. 10 ml buffer B
3. 50 protein extraction filter cartridges
4. 50 collection tubes with cap
5. 2 plastic rods
6. Tissue dissociation beads

Kit components (4 preps):

1. 2.0 ml buffer A
2. 1.0 ml buffer B
3. 4 protein extraction filter cartridges
4. 4 collection tubes with cap
5. 1 plastic rods
6. Tissue dissociation beads

Storage: Store Buffer A and Buffer B at -20°C upon arrival.


Additional Materials Required

1 X PBS
Vortexer
Table-Top Microcentrifuge

Important Information:

1. Read the entire procedures carefully. Thaw buffer A and buffer B completely, invert the bottles a few times and place them on ice. Chill protein extraction filter cartridge with collection tube on ice prior to use.
2. All centrifugation steps should be performed at 4°C in a cold room or in a refrigerated microcentrifuge.
3. To study protein phosphorylation, **phosphatase inhibitors** (such as PhosStop from Roche) should be added to buffer A prior to use. The use of protease inhibitor cocktails is optional.
4. It is recommended to use BCA Protein Assay Kit for determination of protein concentration (Pierce, Cat #:23227).

The Workflow



Membrane Protein Isolation Procedures:

A. Isolation of Total Membrane Proteins



1. Place the filter cartridges in collection tubs and incubate on ice.

2. For cultured cells:

- Collect $1-50 \times 10^6$ cells by low-speed centrifugation ($500-600 \times g$ 5 min). For adherent cells, please see tech note below for cell harvesting.

Note: For isolation of plasma membrane proteins from cultured cells (see below) it's recommended to use $20-50 \times 10^6$ cells.

- Wash cells once with cold PBS ($500-600 \times g$ 5 min). Remove supernatant completely and resuspend the pellet in buffer A (200 μ l for a starting cell number less than 5 million and 500 μ l for a starting cell number greater than 5 million). Incubate the cell suspension on ice for 5-10 min. Vortex the tube vigorously for 10-30 seconds. Immediately transfer the cell suspension to the filter cartridge. Go to step 3.

For tissue samples:

- Place a piece of fresh tissue (10-30 mg) or frozen tissue (20-30 mg) in a filter cartridge. Add 200 μ l buffer A to the filter cartridge and grind the tissue with a plastic rod for one min by pushing the tissue against the surface of the filter repeatedly with twisting force

Note: if you are working with muscles, it is recommended to add 100-120 mg tissue dissociation beads to the filter prior to grinding.

- Add 300 μ l buffer A to the same filter cartridge, mix by pipette up and down a few times and incubate on ice with the cap open for 5 min. Go to step 3.

Note: The presence of a small amount of un-homogenized tissue will not affect the quality of the sample. The plastic rod is reusable. For cleaning, wipe it with 75% alcohol or rinse it with distilled water.

3. Cap the filter cartridge and centrifuge at $16,000 \times g$ for 30 seconds (it is recommended to use a tabletop centrifuge that can reach maximum speed in less than 10 seconds).

Optional: For cultured cells, it is recommended to resuspend the pellet in buffer A, and re-pass through the same filter by spinning at $16,000 \times g$ for 30 seconds. The yield may increase by 20-30%.

4. Discard the filter and resuspend the pellet by vigorously vortexing for 10 seconds.

****The following procedures separate total cellular components into four fractions: nuclei, cytosol, organelles and plasma membrane.***

5. Centrifuge at $700 \times g$ for one min (the pellet contains intact nuclei). Transfer the supernatant to a fresh 1.5 ml microcentrifuge tube and centrifuged at 4°C for 10-30 min at $16,000 \times g$ (longer centrifugation will increase yield). Remove the supernatant (this is the cytosol fraction) and save the pellet (this is the total membrane protein fraction including organelles and plasma membranes). Store the pellet at -70°C or dissolve it in detergent-containing buffers of your choice. The yield is typically 10-500 $\mu\text{g}/\text{sample}$. You may stop here if isolation of plasma membrane proteins is not needed. Continue to step 6 for plasma membrane protein



isolation. Don't freeze total membrane protein fraction if further isolation of plasma membrane proteins is desired.

B. Isolation of Plasma Membrane Proteins:

6. Resuspend the total membrane protein fraction from step 5 in 200 μ l buffer B by repeatedly pipetting up and down or vortexing. Centrifuge at 7,800 X g for 5 min at 4°C (Note: if final plasma membrane prep is contaminated by organelle membranes, increase centrifugation time up to 20 min can improve the purity). The pellet contains organelle membrane proteins.
7. Carefully transfer the supernatant to a fresh 2.0 ml microcentrifuge tube and add 1.6 ml cold PBS. Mix by inverting the tube a few times. Centrifuge at 16,000 X g for 30 min (longer centrifugation will improve yield). Discard the supernatant and save the pellet (isolated plasma membrane). Typically, 10-300 μ g plasma membrane proteins can be obtained. Pellet of plasma membrane can be dissolved in 20-200 μ l detergent containing buffers of your choice depending upon specific downstream applications. Reagents in following table are recommended for solubilization of the pellet. For isoelectric focusing (First dimension of 2D gel) we recommend 7M urea/2M thio-urea/2% Chaps and 20 mM DTT (add DTT to above mix prior to use).

Tech notes:

1. Harvest adherent cells by trypsinization and wash the cells as in step 2. If trypsinization is not feasible, the cells can be harvested by a cell scraper. Scrapped cells should be pipetted up and down repeatedly to contain well-separated cells. Sometimes, it is difficult to obtain accurate cell count with adherent cells. In this case, collect and wash harvested cells by low-speed centrifugation (600 X g 5 min) in a 1.5 ml microfuge tube and compare the wet cell pellet volume to that of 1.5 ml tube containing 40 μ l water. A wet cell pellet of about 40 μ l should be used as starting material for plasma membrane isolation.
2. Buffer A may cause cell lysis for certain cell types, such as Jurkat cells, and clog the filter cartridge. This can be resolved by diluting buffer A 1:1 with 1 X PBS.
3. If Western blotting is used for determining plasma membrane enrichment, a total cell lysate must be included as a positive control with equal protein loading. We recommend anti-Na/K-ATPase antibody (Cat# INSM005AB) as a marker of plasma membrane, and Minute Total Protein Extraction Kit (Cat# SD-001/ SN-002) for unbiased.

Following protein solubilization reagents are recommended.

Product Name	Cat. No.	Applications
Minute™ Denaturing Protein Solubilization Reagent	WA-009	SDS-PAGE electrophoresis and Western blotting, trypsin digestion, purification of proteins with biotin labeling or histidine labeling, etc.
Minute™ Non-Denatured Protein Solubilization Reagent	WA-010	ELISA, immunoprecipitation/Co-IP, enzymatic activity determination and other applications.
Minute™ Protein Solubilization Reagent for MS	WA-011	Trypsin digestion and subsequent mass spectrometry analysis



About Evaluation of Isolated PM Proteins

Many researchers use Western blotting to access the purity of isolated membrane proteins. Some commonly used “cytosolic markers” are not exclusively cytosolic. For example, actin (1), GAPDH (2) and tubulin (3) are mainly cytosolic but they are also associated with plasma membranes. It’s not surprising to detect weak signals of these marker proteins in PM preps in certain cell and tissue types. For more info please refer to following publications:

1. Gruenstein E., et al. (1975). Actin associated with membranes from 3T3 mouse fibroblast and Hela cells. *Journal of cell Biology*. 64:223-234.
2. Terrasse R., et al. (2012). Human and pneumococcal cell surface glyceraldehydes-3-phosphate dehydrogenase (GAPDH) proteins are both ligands of human C1q protein. *J. Biol. Chem.* 287:42620-42633.
3. Wolff J. (2009). Plasma membrane tubulin. *Biochimica et Biophysica Acta. (BBA)-Biomembranes* 1788:1415-1433.

Troubleshooting

Problem	Solution
Low protein yield	Increase starting cell numbers Increase incubation time to 10 min (step 2)
Low protein activity	Keep lysate cold/add protease inhibitors
Retention of cell lysate in protein filter cartridge after 30 seconds of centrifugation	Reduce amount of starting material or increase centrifugation time to 2 min
Contamination of PM by cytosolic proteins	Wash PM pellet with 0.5 ml cold PBS containing 0.3 M NaCl, Ph. 9.5